

Electric Bike Care Instructions

Always read the manual for detailed instructions.

Battery Care

To extend the life of your battery:

Keep your battery at room temperature and avoid exposing it to extreme temperatures

Do not leave your battery in direct sunlight

Do not leave your battery for more than two months without charging it

Batteries like to be charged frequently, the ideal range is to keep your battery between **20 - 80%**

Prevent draining your battery completely

Use the velcro strap around your battery to secure it to the bike frame

Battery Safety

To protect your property and prevent harm:

- Never charge your battery unattended
 - Always have smoke/fire alarms at your property
- Never charge or use a damaged battery - if in doubt, contact your dealer
- When charging on the bike, keep 1-metre of clear space around the bike
- Switch on your charger AFTER plugging it into the bike and the wall socket
 - Only ever use the charger that came with the bike when new
 - We strongly recommend charging through a surge protector

Bike Care

- Lightly rinse your bike with fresh water if exposed to salt water/air
 - Never pressure wash your bike (e.g. water blaster)
 - Dry your bike and components off with a soft dry cloth
- Cover your bike if transporting it in wet weather on car carrier racks
 - Recommended servicing intervals: Check-up 6 weeks after purchase, then every 3-6 months after (higher kms = more frequent service intervals)
 - Check your tyre pressure every fortnight or couple of rides (PSI range is on the tyre sidewall)
- Lubricate your chain every week in Winter, and every two weeks over Summer
 - Clean your bike once a week